



# Room Care R2 – Plus Pur-Eco



## Hard surface cleaner- concentrate

### Description

Concentrated cleaner for the cleaning of all water resistant hard surfaces. To be used only with Divermite/DQFM dosing and dilution system. Also available in fully recyclable mono-material pouch.

### Features

- Formulated for the cleaning of hard, water-resistant surfaces
- Slightly alkaline
- Non-abrasive
- Light, delicate and fresh fragrance
- Uses unique and environmental friendly pouch technology
- Fulfills the criteria of the EU-Ecolabel scheme

### Benefits

- Leaves surfaces thoroughly clean
- Quickly and gently removes oily and water-soluble residues
- Leaves a pleasant scent behind
- Colour and alphanumeric coded to prevent application mistakes

### Application areas

- Lodging
- Office Buildings
- Education
- Healthcare
- Retail

### Environmental information

- Room Care R2-plus Pur-Eco was awarded the license (DK/020/006) fulfilling the EU-Ecolabel criteria as an environmentally friendly product.
- The surfactants used in this product are biodegradable in compliance with the requirement of EU Detergent Regulation, EC 648/2004.
- Fully recyclable mono-material pouch with removable label and cap, so easy to recycle where the required infrastructure exists.



EU Ecolabel: DK/020/006



# Room Care R2 – Plus Pur-Eco



## Hard surface cleaner- concentrate

### Directions for use

**Small areas:** Spray a small quantity onto a damp cloth/sponge pad and clean the surface. Rinse with fresh water or wipe with a clean, damp cloth. Buff with a dry cloth for extra shine.

**Large surfaces/Floor (wet cleaning):** Use a sponge, cloth or mop to apply the solution onto the surface/floor, allow to act briefly (if necessary) and wipe the surface/floor clean. Rinse thoroughly with clean water and allow to dry or wipe with a rinsed in clean water, well-wrung cloth/mop. Buff with a dry cloth/mop for extra shine.

For more detailed application, please refer to Room Care R2-plus Pur-Eco Mini Guide.

### Dosage \*

1. When using with Divermite Room Care dosing unit, dose 1x 15ml (2%) Room Care R2- plus Pur-Eco into keyed bottle filled with 750ml of cold water. Securely screw on the spray trigger, ensure the nozzle is closed and shake gently to mix. Bucket application: Dose 1x 15ml of Room Care R2-plus Pur-Eco into the dispenser ladle and pour ladle's content into 5L water (0.3%).
2. When using with DQFM dilution dispenser unit, fill the Room Care R2-plus Pur-Eco keyed spray bottle to the fill level mark or the bucket directly from the DQFM dispenser. Securely screw-on the spray trigger. Proper dosage saves costs and minimises environmental impact.

*\*This dosage is according to optimal conditions, recommendations may vary, please consult with your Diversey representative for directions. One push is equivalent to 15ml.*

### Technical data

Appearance	Clear dark green liquid	Odour	Product specific
pH (neat)	≈ 10	pH (in-use)	~ 11
Dilution	2% – Spray cleaning .3% – Bucket cleaning	Specific Gravity (20°C)	1.06

*The above data is typical of normal production and should not be taken as a specification.*

Product	Pack size	SKU Code	Availability
Room Care R2-plus Pur-Eco	2 x 2L	101109842	AU & NZ
Room Care R2-plus Pur-Eco – Bottle kit	6 x 750ml	D7524596	AU & NZ

### Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet; [sds.diversey.com](http://sds.diversey.com). Store in original closed containers away from extremes of temperature. Only for professional users / specialists.

### Product compatibility

Do not use on water-sensitive surfaces, e.g. wood. Test material compatibility in a small, inconspicuous place before use. Do not use with other dilution systems or methods. Do not use undiluted.

### Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at [www.diversey.com](http://www.diversey.com) or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.

For additional information, please contact us at:

Diversey Australia Pty Ltd Toll free: 1800 647 779, Diversey New Zealand Ltd Toll free: 0800 803 615 [www.diversey.com](http://www.diversey.com).

Legal disclaimer: The associated products or services are manufactured by or otherwise emanate from Diversey Companies and their subsidiaries and not from Sealed Air.